

Termik



1.




Remove the supports by screwdriver

2.




3.



12x480mm

Medium CA

4.




10x295mm

Medium CA

L+R

5.



Activator

L+R

6.



prepared for the foil covering







7.








use covering film 38 mic with iron on 145°C



8.









24.

Thin CA




25.




26.

Medium CA



27.


Medium CA



28.

use pliers for the 4mm nut

Medium CA




29.




30.

Medium CA



31.


be careful whether it is in the same line



32.


Medium CA

use pliers for the 4mm nut




33.


Medium CA



34.




35.



36.


put the servos in the fuselage
2nd
1st



37.




38.




do not leave the places that will be glued covered with foil

39.

higher horns put in the holes



Medium CA




40. **Medium CA**


The first step to glue the rudder to elevator
The second step glue the tail to the fuselage




41. **Medium CA**



42.



43.




44.

0,8x740mm

Medium CA


put the heatshrink!



45.


click it

put the carbon in bowden



46.

Thin CA




47.

0,8x770mm


Medium CA

put the heatshrink!


48.




49.



50.



51.





52.




53.



54.





We wish you many happy flying hours with the Termik.

Your RC Factory team